Garmin 12 Map – Quick Guide

Buttons:

        RED LIGHT BULB – On/off. Hold down for a few seconds to turn off.

        PAGE – moves forward through main pages.

        QUIT – moves backward through main pages

        MENU – Press once to access submenu for a page

                Press twice to access main menu

        ENTER/MARK – Press to accept a field value

                Hold down to mark a Waypoint

        GOTO – Used to select an existing Waypoint to GOTO.

        IN – Zooms in on Map page.

        OUT – Zooms out on Map page.

Main Pages:

        2 warm up pages

                Status page

                Position page

                Map page

                Compass page

                Highway page

                Active Route page

                        (press MENU button once to get menu for the page ... not the

                            Main Menu).

Main Menu – press the MENU button 2 times

Main Menu Highlights:

        Waypoints – total 500

                Highlight a waypoint, press ENTER, information is displayed

                        about that waypoint.

                Press MENU to see options – can delete or average.

                Average will count the number of positions, press ENTER to save.

         Track Logs – total 10

                Press MENU, select Setup Logging, press ENTER.

                        Record Mode, highlight OFF, press ENTER – displayed is

                                Off, fill, wrap

                        Interval, press ENTER – displayed is

                                Time, resolution, distance

        Trip Computer

                Press ENTER to see fields. Press MENU to see reset options.

        Setup – tabs to select options

                Simulator- leave simulator off, no options.

                System –

                        Beeper – none/message only/key and message

                        Backlight – 15 sec.

                        Power Saver – offers position updates while saving

                              batteries.

                Units

                        Distance and Speed – Statute

                        Heading – True

                        Altitude/Elevation – Feet

                Timers

                        Battery – if on, reset when add new batteries.

                Time

                        Time Format – Local 12hr

                        Local Time Zone – 07:00 PDT, 08:00 PST

                                Behind UTC

                Alarms

                        Clock

                        Arrival – set distance

                        Off Course – set distance

Main Menu Highlights:

                Position
                        Position Format – hddd mm'ss.s''
                        Map Datum – NAD27 CONUS
                Interface
                        Format – Garmin
                        Transfer Mode – Host

To mark a Waypoint:

Press ENTER/MARK button down for a few seconds. Waypoint menu will appear. DONE is highlighted. The position is listed at the bottom of the screen. Press ENTER/MARK button to save waypoint.

To average a Waypoint:

From the Waypoint menu, press the MENU button to access the submenu.
Select Average Position, press ENTER. Once the Measurement Count field has acquired a number of positions, press ENTER to save the waypoint.

Deleting Waypoints:

Deleting One Waypoint - Select Waypoints from the Main Menu, press ENTER. Select Waypoint you want to delete, press ENTER. Press MENU to access submenu and select Delete Waypoint, press ENTER and press ENTER again to confirm.
Deleting All Waypoints - Select Waypoints from the Main Menu, press ENTER.
Press MENU to access submenu and select Delete All. Press ENTER and then press ENTER again to confirm.

Using the GOTO function:

Press the GOTO button. Select an existing Waypoint to GOTO. Screen may display Map page or Compass page. To change field options, displaying different information, press the MENU button and select Change Fields, press ENTER. Press ENTER again to access submenu and select the display option.

Canceling the GOTO function:

Press the GOTO button then press the MENU button. Select Cancel GOTO, press ENTER.

Using the Track function:

Select Track Logs for the Main Menu, press ENTER. From the Track Logs menu, press MENU to access submenu. Select Setup Logging and press ENTER.
Select Record Mode, press ENTER and change OFF to FILL. The tracking option is now activated.